MySQL Backup and Restore using PythonImplement back and restore for MySQL using Python. Mysql - CREATE DATABASE studentrepo; | USE studentrepo; | CREATE TABLE IF NOT EXISTS students (id INT AUTO INCREMENT PRIMARY KEY, name VARCHAR(100), age INT, class VARCHAR(50), city VARCHAR(100), phoneno VARCHAR(20), email VARCHAR(100)); | INSERT INTO students (name, age, class, city, phoneno, email) VALUES ('John Doe', 20, 'Physics', 'New York', '555-1234', 'johndoe@example.com'), ('Jane Smith', 22, 'Computer Science', 'Los Angeles', '555-5678', 'janesmith@example.com'), | show databases | show table ADD MOREpython part-import os | MY SQL PATH = "C:/Program Files (x86)/MySQL/MySQL Server 5.5/bin" | def backup (user, password, database name, backup path, backup file name): command = f"mysqldump -u{user} -p{password} {database name} > {backup path}/{backup file name}"; os.chdir(MY SQL PATH); os.system(command); print("Database Backup Successful") | def recovery(user, password, database name, backup path, backup_file_name): command = f"mysql -u{user} -p{password} {database name}<{backup path}/{backup file name}"; os.chdir(MY SQL PATH); os.system(command); print("Database Recovery successful") | print("Select Operation: \n1. Backup\n2. Recovery"); operation=int(input("Enter operation: ")); if operation==1: backup(input("\nEnter username: "), input("Enter password: "), input("Enter Database Name: "), input("Enter Backup Path: "), input("Enter Backup Name: "),) elif operation==2: recovery(input("\nEnter username: "), input("Enter password: "), input("Enter Database Name: "), input("Enter Backup Path: "), input("Enter Backup Name: "),) else: print("Invalid Operation") | #C:/Users/student/Documents/MYSQLBackup. MYSQL-drop database studentrepo

Data AcquisitionTo perform Data Acquisition using FTK Imager tool and Encase Tool—Download and install FTK Imager tool https://accessdata-ftk-imager.software.informer.com/download/ | Step 2: Add the evidence folder in the tool | Select File -> Add evidence Item -> Contents of a folder and click on next | Add path of the folder and click on finish | File has been added to the evidence tree | Step 3: Now click on File and add the folder or file to make its copy, for that click on Create Disk Image | Step 4: Choose the option "Contents of a folder" and click next | Click yes | Step 5: Browse the folder which we want to make a copy and click Finish | Step 6: Now add the location for the copy document to store it, for that click on Add | Step 7: Fill details | Step 8: After clicking Next, don't change anything, just add the filename and destination folder | Step 9: After Finish, we can see the below page | Step 10: Now click on Start to copy the document | Step 11: Now the new popup will appear where we can verify the HASH values | Step 12: We can see that the folder file is copied to the given location | In that file, we can see the details of the folder.

Encase Tool-Step 1: Download and install Encase tool | Step 2: Select File -> New or click on the new icon to create a new evidence file | Step 3: Enter case details | Step 4: | Step 5: Select File -> Add Device | Step 6: Select Local Drives | Step 7: Choose the drive to create its image (D drive, pendrive) and click Next | After this step, details about the drive will be displayed | Click on Finish | Interface after adding the drive | Step 8: Select Entries -> D | Right-click on D (Drive) and select Acquire | Step 9: Add to Case and click Next | Step 10: Name the case, enter the evidence number and password, and specify the output path | Note - It will take some time for the tool to image the drive depending on the drive size | After Acquisition | After Verification (happens by default after acquisition) | Step 11: Verify evidence file | Select Tools -> Verify Evidence Files | Step 12: Check the report.

Use FTK tool | Steps: Install FTK and after that choose "Start a New Case" | Enter the case details | Enter the following details | Click Next | Select all options | Click Next | Click Next | Add evidence | Click Finish and it will take some time to analyze | Click on Documents | Click on Unchecked Items | Right-click any file -> Create Bookmark | The bookmark will be added, click the Bookmark tab | Right-click the bookmark to delete it | Go to the Search tab -> Indexed Search tab and enter the following keywords | Click "View Cumulative Results" | Add a new keyword, click "Options" and select the following options | Click OK for all | Go to the Live Search tab and add the following keyword | Check "Regular Expression" | Start Search | Click File -> Report Wizard | Enter the following details | Click Next | Click

Autopsy tool: Step 1: Download and install the Autopsy tool | Autopsy Interface | Step 2: Add New Case | Add Case Name and Base Directory | Step 3: Enter Case Information and click Finish | Case Database will be created | For Image 1 - precious.img file | Step 4: Select type of data source - Disk Image and click Next | Step 5: Select Data Source Path (Give Image's path) and click Next | After successfully adding the data source, the below message will be displayed | The tool is analyzing the file | Step 6: Click on the image to view the hexadecimal content of the file | Step 7: To perform a keyword search, select Tools -> Options -> Keyword Search | Step 8: Create a New Keyword List | Step 9: Add New Keywords | Step 10: Select type for keywords - Exact Match | Select type for keywords -Regular Expression | Select type for keywords - Substring Match | Click OK | Keyword List | Step 11: Right-click on precious.img and select "Run Ingest Modules" | Check if "Keyword Search" is selected and click Finish | Step 12: To test Keywords, select Analysis Result -> Keyword Hits -> List 1 (Keyword List Name) | Step 13: Generate a Report of the Examination | Step 14: Open Report File | For Image 2 - sample1.img file | Step 1: Select type of data source -Disk Image and click Next | Step 2: Select Data Source Path (Give Image's path) and click Next | After successfully adding the data source, the below message will be displayed | The tool is analyzing the file | Step 3: Click on the image to view the hexadecimal content of the file | Step 4: To perform a keyword search, select Tools -> Options -> Keyword Search | Step 5: Create a New Keyword List | Step 6: Add New Keywords | Step 7: Select type for keywords - Exact Match | Select type for keywords - Regular Expression | Select type for keywords - Substring Match | Click OK | Keyword List | Step 8: Right-click on sample1.img and select "Run Ingest Modules" | Check if "Keyword Search" is selected and click Finish | Step 9: To test Keywords, select Analysis Result -> Keyword Hits -> List 2 (Keyword List Name) | Step 10: Generate a Report of the Examination | Step 11: Open Report File.

Perform Email Forensics using Outlook and Forensic Tool 1.8.2 | Steps: Create an Outlook account | Send email to personal email | Click send | Check sent items | Check received email | Send email to Outlook | Check received email in Outlook | Delete email | Check deleted items | Click File and then click Open & Export | Click Export and select export to a file | Select .pst | Select Deleted Items, Inbox, and Sent Items | Specify path | Set password | Type the password again | Backup file is created | Open AccessData Forensic Tool | Start new case and enter case details | Enter the following details | Click next | Click next | Select email emphasis | Click next | Click add evidence and select individual file | Select the backup.pst file | Enter the following | Evidence is added | After the processing is done | Click Email Messages | Click any message | Go to Email tab and expand the backup.pst file | For jimsin.pst's inbox mails | Backup the case.

Perform Browser Forensics using Browser History Examiner Tool | Note: Clear browsing history from all browsers before starting (trial version displays only first 25 records) | Steps: Download, Install, and Open Browser History Examiner | Click File > Capture History | Click Next | Specify location | Click Capture | Search something in the browser | Dialog box appears, click Yes | Report is generated | Click File > Load History | Select the capture folder | Report preview | Explore all items | Click File > Export > Export as HTML | Click Export | Open the report | Add records to reports by marking the STAR | Click File > Report > Save as PDF | Open the report.

S-Tool Steps: Step 1: Download steg.zip (https://www.cs.vu.nl/~ast/books/mos2/steg.zip), unzip, and run S-Tools | Step 2: Download a .gif or .bmp image | Step 3: Drag and drop the image into S-Tools (add to steg folder) | Step 4: Create a text file, add content, and drag it onto the image | Step 5: Add a passphrase, select an encryption algorithm, and a new image (hidden data) will be created | Step 6: Decrypt the hidden message by right-clicking the file, selecting Reveal, and entering the same passphrase | Step 7: Right-click the text file, select Save As, and open it

SteganPEG Steps: Step 1: Install SteganPEG

(https://www.softpedia.com/get/Security/Encrypting/SteganPEG.shtml) and select "Embed files into a JPEG image" | Step 2: Enter an encryption password, download a .jpg image, add its path, and click GO! | Step 3: Create a text file with content, add it, and save the stegged image | Step 4: Select "Read files from a JPEG image" for decryption and add the stegged image path | Step 5: Enter the same password, extract the file, and view its contents.